

# Hearing Aid Instructions



**On** (door closed)



**Off** (door open)



For left ear

**Blue**

For right ear

**Red**



Change your battery every 7-10 days or when it beeps to tell you



Use orange battery packets



Insert correct way up



Yes





No




# Beeps, Batteries and Telecoil



Beeps when turns on  Yes

Beeps when button pressed  Yes

Beeps when battery needs changing  
 Yes



Louder (volume up)

Quieter (volume down)

Telecoil Loop  
available?



Yes





No

You can use the Telecoil where you see this sign


Portable Induction Loop



Bank or Post Office  Yes

Cinema or Theatre  Yes

Church  Yes

Home (Tv and telephone)  No

You need special equipment to use it at home

Telecoil on (press 1 second)

Telecoil off (press 1 second)





## **Change program (press 1 second)**

**Program 1:**

**Program 2:**

**Program 3:**

**Both hearing aids will change program together**

